

Installation instructions for PZ4AL-3007-00, PZ4AL-3008-00  
Under Run Protective Shield Fuel Tank

## TOYOTA LC 200



## LEXUS LX



### LC 200 (4.6L; 4,5TD)

### LX 570

### LX 450d

Model year:

2015

2015

2015

Applicability:

VDJ200L-GMTVZW

Part Number:

Steel: PZ4AL-3007-00  
Aluminium: PZ4AL-3008-00



Weight:

Steel: 17.27 kg  
Aluminium: 10.25 kg




Installation Time:

30 min

PZ4AL-03007-00, PZ4AL-3008-00

**A**



PZ4AL-01588-60

**B**




1x

**C**




1x

**D**




1x

**E**



2x


**F**



h=10

2x


**G1**



M8x30

5x


**G2**



M10x20

3x


**G3**



M10x30

2x


**H1**



d=8

5x

**H2**



d=10

5x


**I1**



d=8


5x

**I2**





d=10

5x






13 mm  
17 mm










**3**




**4**



**5**



**6**



Part number:  
PZ4AL-3007-00  
PZ4AL-3008-00

Revision:  
1

Date:  
02.12.15

LC 200 2015; LX 450d 2015

Page:  
5/6

7

END

